



Neksia 550 allows you to expand the field of possibilities with high-curve function







NEKSIA 550

EVERYTHING THE NEXT-GENERATION KAPPA OFFERS AND MORE!

1

RACE THROUGH WORKLOADS





- Automatic binocular tracing in 3 dimensions
- Bevel: 3D bevel preview and configurable bevel trajectory
- Grooving: configurable positioning, width and depth
- Chamfering: front face and/or back face, by flexible chamfering wheel
- Polishing: flat and bevel
- More ergonomic centering (wide open space)
- EAS (Edging Assisted System) cycle to avoid axis deviation on fragile lenses
- 1,000 positions job database



'HIGH CURVE' FUNCTION EXPAND THE FIELD OF POSSIBILITIES



- Base curve coverage to 8, for all materials except mineral, with adjustable bevel height, width and location
- Go for quality finished jobs instead of ill-fitted lenses and decrease the number of re-do's
- Dispense a greater variety of glasses with wrap-around frames



- Edging mineral lenses with Neksia 550 is not possible.
- For further information and specifications on the Neksia line in general, please consult the Neksia brochure.

